

219 East Main Street Mechanicsburg, PA USA 17055 Toll Free: 866-EESIFLO Fax: (717) 697-2122



<u>Charging the Battery</u> <u>in your EESiFlo 6000 Series</u> <u>Portable Ultrasonic Flow Computer</u>

- 1) Plug the wall mounted power supply into the rear of the 6000 Series input marked "9 ... 12 VDC" then plug it into the nearest 110 VAC wall receptacle.
- 2) Turn the 6000 Series ON by pressing the ON (C) button
- 3) Navigate to the SF (Special Function) menu by pressing the 6 or 4 buttons
- 4) Navigate to "Charge Battery" by pressing the 2 or 8 button
- 5) Press the ENTER button and the 6000 Series will indicate how much time is required to charge the batteries.
- 6) Press the ENTER button again and the red LED next to BATTERY will light, and the LCD will display how many hours are expected to complete the charge.
- 7) Press ENTER again and the display will ask "Stop Charging" <NO> YES
- 8) Press ENTER to accept NO and the unit will return to the main menu of options and permit you to continue measurements.